
KOOIJ BV
KANONNENLOODS 24
1505RX ZAANDAM
THE NETHERLANDS

OFFICE@KOOIJ.COM
KOOIJ.COM



Accrete

USER GUIDE

TOUCH SWITCH & DIMMER GUIDE

for

ACCRETE

The *Accrete* has no mechanical switch. Instead, its touch sensor responds to the natural electrical capacitance of the human body, allowing you to switch and dim the light with a simple touch of your fingertip.

As this technology relies on electrical capacitance rather than pressure, its sensitivity can vary depending on your connection to the ground. When standing barefoot, particularly on stone, tile, concrete or heated floors, you may notice that the sensor responds less readily. This is a natural characteristic of capacitive touch technology and does not indicate a fault with your lamp.

Operation

- *Short touch:* Switch the lamp on or off.
- *Touch and hold:* Adjust the brightness. Release when the desired level is reached.
- *Brightness memory:* The lamp remembers the last brightness setting and returns to it when switched on.

Please note

At its lowest dimming level, *Accrete* may appear to be switched off, even though the lamp is still on. At this setting, the short-touch on/off function is temporarily disabled.

If the lamp appears unresponsive when trying to switch it on or off, touch and hold the sensor to increase the brightness. Once the brightness has increased sufficiently, the short-touch function will work again.

Please remember that dimming the lamp all the way down does not switch it off completely. Always use a short touch to switch the lamp off.

For the best experience

- Touch the sensor while wearing shoes or slippers, or standing on a rug.
- Use a gentle, deliberate touch of your fingertip.
- If the sensor seems less responsive, try reversing the plug or using a different socket.

If you encounter any issues, please do not hesitate to contact us at the address below.

kooij.com | office@kooij.com | +31 (0) 85 876 9629
Kanonnenloods 24 | 1505 RX Zaandam | NL

CARE INSTRUCTIONS
for
ACCRETE

The *Accrete* is extruded from recycled polycarbonate, one of the most durable plastics available, and is designed for many generations of use.

To care for your *Accrete* and keep it looking its best, we recommend regular dusting by using a dry microfibre cloth or low-pressure compressed air. For deeper cleaning, wipe with a soft cloth and a pH-neutral soap, then dry immediately.

The LED lights housed within Accrete are guaranteed for a minimum of 50,000 hours and will not need to be replaced.

For reliable operation, please use the dimming button with clean, dry hands. Residue from lotions, creams, or oils can interfere with the touch sensor and prevent it from responding correctly.

What to avoid
- Outdoor use
- Sharp or very hard objects placed or moved directly across the surface
- Acetone and other chemical cleaners
- Abrasive sponges or cloths
- Direct heat exposure exceeding 80°C
- Prolonged contact with rusted items or other staining substances

If you encounter any issues, please do not hesitate to contact us at the address below.

kooij.com | office@kooij.com | +31 (0) 85 876 9629
Kanonnenloods 24 | 1505 RX Zaandam | NL